

# SuperBrace

## THE ULTIMATE FORK BRACE

---

### SuperBrace Part # 2318

---

#### Installation instructions

**Fits Model: Honda Goldwing GL 1800 w/Fork Protectors**

**Years: (2001-2006)**

1. Place motorcycle on center stand.
2. Remove front half of fender.
3. Remove Honda chrome cover.
4. Put lower dust covers in place on the bottom of the SuperBrace.
5. Loosen axle pinch bolts.
6. Assemble SuperBrace at bottom of fork seals. (Lower Dust covers will curve behind bolt heads).
7. Torque SuperBrace bolts to 10 ft. pounds.
8. Bounce front end of motorcycle, then re-torque axle pinch bolts to factory specifications.
9. Put front fender back in place. Adjustment may be required on lower dust covers if the fender does not fit properly. Replace the (4) bolts to secure the fender.

**IMPORTANT: Before riding, bounce the front end of motorcycle and cycle the suspension to insure brake lines and horn *Do Not* contact the brace. It may be necessary to move or purchase after market brake lines and horn.**

---

#### MADE IN USA

SuperBrace is a registered trademark and is covered under one or more of the following patent numbers: 4,742,885 and/or 4,854,412.

#### 30 DAY GUARANTEE

If you are dissatisfied with your SuperBrace for any reason, please return it to us, postage paid within 30 days of the date of invoice. If the product has not been damaged or modified we will provide a full refund, No questions asked.

---

[www.superbrace.com](http://www.superbrace.com)

Phone (800) 322-4783 or Fax (714) 842-0866

---